



1-877-287-5017



Feather Wheel Instructions


Parts

- ▶ Carriage Bolt
- ▶ 2 Washers
- ▶ Metal Bushing
- ▶ Feather Wheel
- ▶ 1-3/8" Thru Knob

Optional parts are available on our website



Setup



Note:

- With the Feather Wheel collapsed at:

- 1/8" = 6.8lbs pressure
- 1/4" = 16.9lbs pressure
- 3/8" = 30.4lbs pressure
- 1/2" = 50.9lbs pressure

- The Feather Wheel collapses the best at 1/8 to 1/4".

Feather Wheel Holder Drawing

Optional

